

# FloPoCo 1.15.0 developer manual

Florent de Dinechin, Bogdan Pasca

July 20, 2009

Welcome to new developers!

The purpose of this document is to help you design an operator within the FloPoCo project.

## 1 Getting started with FloPoCo

### 1.1 Getting the source and compiling using CMake

It is strongly advised that you work with the svn version of the source, which can be obtained by following the instructions on [https://gforge.inria.fr/scm/?group\\_id=1030](https://gforge.inria.fr/scm/?group_id=1030). If you wish to distribute your work with FloPoCo, contact us.

If you are unfamiliar with the CMake system, there is little to learn, really. When adding .hpp and .cpp files to the project, you will need to edit `CMakeLists.txt`. It is probably going to be straightforward, just do some imitation of what is already there. Anyway `cmake` is well documented. The web page of the CMake project is <http://www.cmake.org/>.

### 1.2 Overview of the source code

In FloPoCo, everything is an `Operator`. `Operator` is a virtual class, all FloPoCo operators inherit this class. A good way to design a new operator is to imitate a simple one. We suggest `Shifter` for simple integer operators, and `FPAdder` for a complex operator with several sub-components. An example of assembling several FP operators in a larger pipeline is `Collision`.


Meanwhile, browse through `Operator.hpp`. It has become quite bloated, showing the history of the project. Try not to use methods flagged as deprecated, as they will be removed in the future. Instead, use the automatic pipeline framework is described in Section 2 below.

Another important class hierarchy in FloPoCo is `Target`, which defines the architecture of the target FPGA. It currently has two sub-classes, `VirtexIV` and `StratixII`. You may want to add a new target, the best way to do so is by imitation. Please consider contributing it to the project.

To understand the command line, go read `main.cpp`. It is not the part we are the most proud of, but it does the job.

The rest is arithmetic!

And do not hesitate to contact us: `Florent.de.Dinechin` or `Bogdan.Pasca`, at `ens-lyon.fr`



## 2 Pipelining made easy: a tutorial

Let us consider a toy MAC unit, which in VHDL would be written

```

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_arith.all;
use ieee.std_logic_unsigned.all;
library work;

entity MAC is
    port ( X    : in  std_logic_vector(63 downto 0);
          Y,Z  : in  std_logic_vector(31 downto 0);
          R    : out std_logic_vector(63 downto 0) );
end entity;

architecture arch of MAC is
    signal T: std_logic_vector(63 downto 0);
begin
    T <= Y * Z;
    R <= X + T;
end architecture;
  
```

We chose for simplicity a fixed-size operator, but all the following works as well for parameterized operators.

We have above the description of a combinatorial circuit. We now show how to turn it into a pipelined one.

### 2.1 First steps in FloPoCo

FloPoCo mostly requires you to copy the part of the VHDL that is between the `begin` and the `end` of the architecture into the constructor of a class that inherits from `Operator`. The following is minimal FloPoCo code for `MAC.cpp`:

```

#include "Operator.hpp"

class MAC : public Operator
{
  
```

```

public:
// The constructor
MAC(Target* target): Operator(target)
{
setName("MAC");
setCopyrightString("ACME MAC Co, 2009");

// Set up the IO signals
addInput ("X" , 64);
addInput ("Y" , 32);
addInput ("Z" , 32);
addOutput("R" , 64);

    vhdl << declare("T", 64) << " <= Y * Z;" << endl;
    vhdl << "R <= X + T;" << endl;
}

// the destructor
~MAC() {}

```

And that's it. `MAC` inherits from `Operator` the method `outputVHDL()` that will assemble the information defined in the constructor into synthesizable VHDL.

So far we have gained little, except that it is more convenient to have the declaration of `T` where its value is defined. Let us now turn this design into a pipelined one.

## 2.2 Basic pipeline

Let us first insert a synchronization barrier between the result of the multiplication and the adder input. The code becomes:

```

(...)
    vhdl << declare("T", 64) << " <= Y * Z;" << endl;
    nextCycle();
    vhdl << "R <= " << use("X") << " + " << use("T") << ";" << endl;
(...)

```

Now this code will produce a properly synchronized pipelined operator with `-pipeline=yes`, and will produce a combinatorial operator (the same as previously) with `-pipeline=no`.

How does it work?

- `Operator` has a `currentCycle` attribute, initially equal to zero. The main function of `nextCycle()` is to increment `currentCycle`.
- Every signal declared through `addInput` or `declare` has a `cycle` attribute, which represents the cycle at which this signal is active. It is 0 for the inputs, and for signals declared through `declare()` it is `currentCycle` at the time `declare` was invoked.
- Every signal also possesses an attribute `lifeSpan` which indicates how many cycles it will need to be delayed. This attribute is initialized to 0, then possibly increased by `use()` as we will see below. When the `lifeSpan` of a signal `X` is greater than zero, `outputVHDL()` will create `lifeSpan` new signals `X_d1`, `X_d2` and so on, and insert registers between them. In other words, `X_d2` will hold the value of `X` delayed by 2 cycles.
- Wrapping a signal in `use()` has the following effect. First, `use("X")` will compare `currentCycle` and the `cycle` declared for `X`, which we note `X.cycle`.

- If they are equal, or if `-pipeline=no`, `use("X")` will simply return "X".
- If `currentCycle < X.cycle`, `use("X")` will emit an error message complaining that X is being used before the cycle at which it is defined.
- If `currentCycle > X.cycle`, `use("X")` will delay signal X by `n=currentCycle-X.cycle` cycles. Technically `use("X")` just returns "X\_dn", and updates `X.lifeSpan` to be at least equal to n.

It should be noted that this scheme gracefully degrades to a combinatorial operator. It also automatically adapts to random insertions and suppressions of synchronization barriers. Typically, one synthesizes an operator, and decides to break the critical path by inserting a synchronisation barrier in it. This may be as simple as inserting a single `nextCycle()` in the code. FloPoCo takes care of the rest.

It is also possible to have ifs before some of the `nextCycle()`, so that the pipeline adapts to the frequency, the operator generic parameters, etc. See `IntAdder` for an example.

Some more notes:

- The second parameter of `declare()`, the signal width, is optional and defaults to 1 (a `std_logic` signal).
- Other functions allow to manipulate `currentCycle`. They are `setCycle(int n)`, `setCycleFromSignal(string s)` which sets the `currentCycle` to the cycle of the signal whose name is given as an argument (going back if needed), and `syncCycleFromSignal(string s)` which may only advance `currentCycle`. The latter allows to synchronise several signals by setting `currentCycle` to the max of their `cycle`. See `FPAdder` or `FPLog` for examples of such synchronisations.

All these functions have an optional boolean second argument which, if true, inserts in the generated VHDL a comment “- entering cycle n”.

- If our toy example, is part of a larger circuit such that X is itself delayed, the pipeline will adapt to that.

## 2.3 Advanced pipeline with sub-components

We now show how to replace the + and \* with FloPoCo pipelined operators. These operators support frequency-directed pipelining, which means that the resulting MAC will also have its pipeline depth automatically computed from the user-supplied frequency.

```
(...)
// vhdl << declare("T", 64) << " <= Y * Z;" << endl;

IntMultiplier my_mult = new IntMultiplier(target, 32, 32);
oplist.push_back(my_mult); // some day this will be an addOperator method
inPortMap (my_mult, "X", "Y"); // formal, actual
inPortMap (my_mult, "Y", "Z");
outPortMap (my_mult, "R", "T");
vhdl << instance(my_mult, "my_mult"); // 2nd param is the VHDL instance name
// advance to the cycle of the result
syncCycleFromSignal("T");

// pipelined operators do not have a register on the output
nextCycle();

// vhdl << "R <= " << use("X") << " + " << use("T") << ";" << endl;
```

```

IntAdder my_adder = new IntAdder(target, 64);
oplist.push_back(my_adder);
inPortMap    (my_adder, "X", "X");
inPortMap    (my_adder, "Y", "T");
inPortMapCst(my_adder, "Cin", "0"); -- carry in
outPortMap   (my_adder, "R", "RR");
vhdl << instance(my_adder, "my_add");
    // advance to the cycle of the result
syncCycleFromSignal("RR");
    vhdl << "R <= RR;" << endl; // no need for use since we are in the same cycle
(...)

```

And that's it. In the code above, an `inPortMap()` does the same job as a `use()`, and an `outPortMap()` does the same job as a `declare()`, although it doesn't need a signal width since it can read it from the sub-component. `instance()` also has the effect that `outputVHDL()` will declare this component in the VHDL header of `MAC`.

### 3 Test bench generation

The command

```
flopoco FPAdder 8 23 TestBench 500
```

produces a test bench of 500 test vectors to exercise `FPAdder`.

#### 3.1 Operator emulation

It requires only one additional method, `emulate`. As the name indicates, this method provides a bit-accurate simulation of the operator.

- Most operators should be fully specified: for a given input vector, they must output a uniquely defined vector. Imitate `IntAdder` for an integer operator. For floating-point operators, this unique output is the combination of a mathematical function and a well-defined rounding mode. The bit-exact MPFR library is used in this case. Imitate `FPAdder` in this case.
- Other operators are not defined so strictly, and may take several output values. The last parameter of `addOutput` defines how many values this output may take. An acceptable requirement in floating-point is *faithful rounding*: the operator should return one of the two FP values surrounding the exact result. These values may be obtained thanks to the *rounding up* and *rounding down* modes supported by MPFR. See `FPLog` for a simple example, and `Collision` for a more complex example (computing the two faithful values for  $x^2 + y^2 + z^2$ ).

#### 3.2 Operator-specific test vector generation

Overloading `emulate()` is enough for `FloPoCo` to be able to create a generic test bench using random inputs. However, function analysis also allows for better, more operator-specific test-case generation. Let us just take two examples.

- A double-precision exponential returns  $+\infty$  for all inputs larger than 710 and returns 0 for all inputs smaller than  $-746$ . In other terms, the most interesting test domain for this function is when the input exponent is between  $-10$  and  $10$ , a fraction of the full double-precision exponent domain ( $-1024$  to  $1023$ ). Generating random 64-bit integers and using them as floating-point inputs would mean testing mostly the overflow/underflow logic, which is a tiny part of the operator.

- In a floating-point adder, if the difference between the exponents of the two operands is large, the adder will simply return the biggest of the two, and again this is the most probable situation when taking two random operands. Here it is better to generate random cases where the two operands have close exponents.

Such cases are managed by overloading the Operator method `buildRandomTestCases()`. Finally, `buildStandardTestCases()` allows to test corner cases which random testing has little chance to find.